






Replacement Sheet



**FIG. 4**



**Fig. 17**



**Fig. 18**




Fig. 19






Fig. 20



2540

**Fig. 21**



**Fig. 22**

Module Tests and Commands	
Reset Test	^
Self Test	
Sensor State Test	
Firmware Download	v
Lead through Test	
Set AFD Communication	
Get Cassette Information	
Calibrate	
Generate Engineering Data (DAQ) Test	
Diverter Test	
Exit Shutter Test	
Last Assert Test	
Motor Test	
Push Plate Test	
Transport Test	
Tray Test	

Fig. 23



Diebold Diagnostics

Terminal Status

Modules

Version Info

Configuration

Metrics

Self Tests

Status Log

Service Calls

Service Docs

Status & Tests

Service Calls

Status Log

Version Info

Configuration

Metrics

Service Docs

Address: D:\Techpos\BOOKSTM200001\001\1030001\html\S5173002

Go

Back

Forward

Home


### 4.1.2 Replacement


To replace the fascia plate, reverse the removal procedure.  
Grease the gate with Diebold lubricant (PN 16-003082-000A) before

Figure 4-1 Removing the Lead-through Indicator and Exit


42422A23

**Fig. 24**







**Fig. 30**



**Fig. 31**



**Fig. 32**



**Fig. 33**